



Pos. Nr. Pos.no.	Beschreibung Description	Art.-Nr. Art.no.	Preisgruppe Price bracket
731319	SBB Re 460	=	N
731399		=	N
1	LOKGEHÄUSE KPL. Body assembly complete	10731319	039
2	LICHTABDECKUNG -SATZ Light cover - set	12731302	011
3	LICHTL.-STIRNL.-FÜHRERST.-HIMM Light conductor/front light&driver's cab	13731302	011
4	STIRNFEN.-FÜHRERHAUSEN.-SATZ Window set front/driver's cab - set	14731302	019
5	ZUGSAMMELSCHIENENDOSE Train power supply line socket	19731302	004
6	LOKRAHMEN Loco framework	30731404	011
7	FRONTSCHÜRZEN-SATZ Set of front skirts	33731302	016
8	KUKU-DEICHSEL Short coupling reception	38702300	007
9	LOKFAHRGESTELL OHNE MOTOR Loco chassis w/o motor	40731404	020
10	DREHGESTELLRAHMEN/SATZ Bogie framework - set	41731302	011
11	DEICHSELABDECKUNG-SATZ Shaft cover plate - set	43731302	011
12	DREHGESTELLBLOCK KPL. Bogie block	45731302	017
13	MOTOR Motor	50731302	031
14	KOHLHALTER Brush holder	00507801	001
15	ACHSE Z.DREHGESTELLBEFESTIGUNG Bogie fixation pin	00527002	002
16	RADSATZ KPL.M.Z.O.N. Wheelset cpl. w.gear wheel,w/o trac.ty.	53713500	014
17	RADSATZ KPL. M.Z.M.1 N. Wheelset cpl. w.gear wheel,w.1 trac. ty.	53713600	014
18	HAFTREIFEN Traction tyre	00547002	001
19	ZAHNRAD Z:13 Gear wheel Z=13	00567149	006
20	SCHNECKE Worm gear	56762100	008
21	ROHR Brass tube	00567770	002
22	LEITERPLATTE KPL. PCB complete	65714800	022
23	BRÜCKENSTECKER Jumper	66710500	013
24	EINHOLMSTROMABNEHMER Single arm pantograph	67706600	025
25	LINSENSCHRAUBE M 1,2 X 3 H Button screw M1,2 x 3 H	70900005	002
26	GF-SCHRAUBE M1,6X5 DIN7500 Self-tapping screw M1,6x5 DIN 7500	70900013	001
27	PUFFER-SATZ Buffer - set	75707200	011
28	DEICHSELFEDER Spring for rod	76702400	001
29	ERSATZ-SCHLEIFKOHLEN Carbon brushes set	6518	---
30	STANDARD-STECKKUPPLUNG Clip-in coupling	9525	---
31	PROFI-STECKKUPPLUNG Profi clip-in coupling	9545	---
Sound			
32	ABSTANDSHALTER (LAUTSPRECHER) Spacer for loudspeaker	12731474	006
33	LEITERPLATTE KPL. (mit Sound) PCB complete (with sound)	65715600	035
34	LAUTSPRECHER Loudspeaker	68701100	016